

Automatic High Airflow Cool Down to Sleep ✓ Protect desoldering handpiece ✓ Extend service life of heater ✓ Compact and ergonomic handpiece Display Descriptions Channel Temperature Unit Temperature Unit CH2 Sleep Mode Password Setting Voice Control ON Buzzer ON

Heating ower Bar

Press the UP&Dow enter the calibration

> Voice Control Free your hand

200

50 350 100 3

CH2

nel 2

Button Descriptions

One-click Cooling

Passw<u>ord</u> Setting Voice ON/OFF

Note: A prompt will pop-up when each function is enable/disabled

Quality lies in Details

400 120 500 200

СНЗ

CH4

Switch Interface

(^>) at once to switch °C/°F

ey, QUICK

Heat Dissipation Grid Air circulation helps to dissipated



1300W 50 ~ 550°C

NK1130 NK2084 NK2064

NK2127

214*235*159mm About4.3kg

70L/Min (Max) Scale of 1-200

Packing List

Power

Nozzle


Weight

Dimensions

Airflow Rate

Airflow Range

Temperature Range



Handpiece Holder×1



Nozzles×4